






Space between pressure plate and supporting column should be kept free from fixed installations!

(MOVABLE)




Free space can be reduced to this distance on one of the sides




A-A:

C-C:



ISO 7 - R 1 1/4



ISO 7 - R 1 1/4

All dimensions in millimeters (mm)

NO. OF UNITS


1



www.alfalaval.com

TL3-BFG

PED Article 4.3



8240123493

Do not use this drawing for foundation bolting or piping layout

DATE 2/25/22
REVISION 0