











Space between pressure plate and supporting column should be kept free from fixed installations!

(MOVABLE)



A-A:

C-C:



All dimensions in millimeters (mm)

NO. OF UNITS

1

GASKET


CHANNEL ARRANGEMENT 1*24 H
/ 1*25 H



www.alfalaval.com

TL3-BFG

PED Article 4.3



| |
|------------|
| 8240123444 |
|------------|

Do not use this drawing for foundation bolting or piping layout

DATE 2/25/22
REVISION 0