





Space between pressure plate and supporting column should be kept free from fixed installations!

\*) Recommended free space for opening and closing to be applied on both sides

[illegible]

(MOVABLE)



NO. OF UNITS

1

ML  
MH

CHANNEL ARRANGEMENT 1\*24 ML  
/ 1\*25 MH



# T6-PFG

Do not use this drawing for foundation bolting or piping layout

DATE 2/21/22  
REVISION 0